

# YOUR ULTIMATE GUIDE FOR WHEN TO REPLACE HOUSEHOLD APPLIANCES



## Common Appliance Life Spans and Signs a Replacement Is Needed



### Washer — life span of 10 years

- The unit is leaking water
- Water does not fill or drain from the drum
- Extreme shaking or noisiness



### Dryer — 13 years

- Burning or abnormal smells
- Clothing is still damp or wet after drying
- Excessively noisy drying cycles



### Refrigerator — 10-12 years

- Condensation on the outside
- Inadequate cooling power has food spoiling quickly
- The back of the unit is hot to the touch



### Dishwasher — 9 years

- Water no longer heats
- Dishes come out dirty
- The door latch does not work properly



### Range (includes stove, burners and oven) — 10-15 years

- Heating elements are broken
- Oven coils heat unevenly
- Control panels are non-operational



### Microwave — 10-12 years

- Emits sparks or smoke
- Keypad is non-functional
- Food is not cooking correctly



### Coffee maker or espresso machine — 5 years

- Machine is leaking
- Water does not get hot enough
- Pump is broken



**HEATING  
&  
COOLING**